


MF1-B4 系列 快速安裝手冊

產品外觀圖與包裝內容物

前視圖



背視圖



A 讀取LED燈

B CFexpress卡槽 (Type B)

C 風扇轉速開關

D USB-C 埠 (僅供5V電源輸入)

E USB4.0 Type-C (40Gbps)

F 風扇

包裝內容物：

- MF1-B4 x1
- 速安裝手冊 x1
- USB3.2 Type-C to Type-A 線 x1
- USB4 Type-C to Type-C 線 x1
- 零件包

請注意：

- 請檢查產品和所有隨附附件是否有損傷或缺失零件。如果您遇到任何問題，請聯絡您的產品供應商。
- 如需更多資訊、資源和下載相關資料，請造訪STARDOM 官方網站www.STARDOM.com.tw。

注意：開啟產品電源前，請確認產品與主機端 (開機狀態) 已連接，否則產品將進入休眠狀態。



1

v0.1 (Jan. 2026)


燈號說明

狀態	硬碟 LED 燈狀態
CFexpress卡閒置	藍燈恆亮
資料存取中	藍燈閃爍
沒有卡 或 卡損毀	----

硬體安裝

請參照下列步驟安裝 MF1-B4：

- 連接纜線：**使用隨附的USB線連接MF1-B4與PC/Mac。
- 插入CFexpress卡：**將CFexpress卡 (Type B)插入MF1-B4。



- 開啟電源：**請開啟系統電源，作業系統應會自動偵測硬碟。
- 格式化CFexpress卡：**如果必要，請依照作業系統指示格式化記憶卡。

請注意：

- MF1-B4 預設使用 USB 匯流排供電。如需使用 5V DC 供電，請先連接 USB-C 4.0 線，再插入 5V DC 轉接器。

2

使用前注意事項

- 靜電接地：**將自己接地來防止靜電
- 拔掉電源：**安裝前關閉電腦並拔掉電源插頭
- 使用無靜電表面：**避免在地毯或導電表面上作業
- 閱讀說明：**開始安裝前查看所有步驟
- 安全移除：**在移除USB線之前，請務必透過作業系統安全移除MF1-B4。

3

感謝您選擇 STARDOM 產品!

請注意，本手冊中的資訊在出版時是正確的，但產品規格在出貨前可能已變更。有關最新規格與更新，請造訪 www.STARDOM.com.tw 或聯絡您的經銷商。

如果您對 STARDOM 產品有任何疑問，或是要取得最新的產品手冊或軟體更新，請發送電子郵件到 supporting@raidontek.com


4

MF1-B4 Series Quick Installation Guide

Product Diagrams and Package Contents

Front View

Rear View



- A** Disk LED
- B** CFexpress Card Slot (Type B)
- C** Fan Speed Switch
- D** USB-C Port (for 5V DC Input Only)
- E** USB4.0 Type-C (40Gbps)
- F** Fan

Package Contents:

- MF1-B4 x1
- Quick Installation Guide x1
- USB3.2 Type-C to Type-A Cable x1
- USB4 Type-C to Type-C Cable x1
- Accessories

Please Note:

- Check the product and all included accessories for defects or missing parts. If you encounter any issues, contact your product supplier.
- For additional information, resources, and downloads, please visit the STARDOM official website at www.STARDOM.com.tw.

NOTE:
Please make sure that the product is connected to the host (power on status) before turning on the power, otherwise the product will be on the sleep mode.



1

v0.1 (Jan. 2026)


Disk LED Status Guide

Status	Disk LED Status
CFexpress Card Idle	Blue light always on
Data Access	Blue light flashing
No Card or Card Failure	-----

Hardware Installation Guide

Follow these steps to install the MF1-B4:

- 1. Connect the Cables:** Use the included cable to connect the MF1-B4 and PC/Mac.
- 2. Install the CFexpress Card:** Insert the CFexpress Card (Type B) into the MF1-B4.



- 3. Power On:** Turn on the system; the OS should auto-detect the disk.
- 4. Format CFexpress Card:** Follow OS prompts to format the card if necessary.

Please Note:

- The MF1-B4 operates on USB bus power by default. If you need to use the 5 V DC input for additional power, connect the USB-C 4.0 cable first, then plug in the 5V DC adapter.

2

Precautions Prior to Use

- 1. Ground Yourself** – Safely discharge static by grounding before handling components.
- 2. Unplug Power** – Power off and unplug the computer before installation.
- 3. Use a Static-Free Surface** – Avoid carpets or conductive materials.
- 4. Read Instructions** – Review all steps thoroughly before proceeding.
- 5. Safely Remove** – Always safely removed MU1-B4 through the operating system before remove the USB connection.

3

Thank you for choosing STARDOM products!

Please note that the information in this manual was accurate at the time of publication, but product specifications may have changed prior to shipping. For the latest specifications and updates, visit www.STARDOM.com.tw or contact your sales representative.

For any inquiries about STARDOM products, or to receive the latest product manuals or firmware updates, please email us at: supporting@raidontek.com.

4